

Columbus Airport Maintenance Department
Hangar Work Orders October 30th – November 15th, 2019

12- Overhead light fixture is missing; order and replace.

12 – Electrical panels are missing from breaker boxes and disconnects; need to be re-installed.

12 – Doors do not roll smoothly; re-inflate tires on motorized door operators.

13 – Install bird netting in the rafters to prevent pigeon roosting.

14 – Install bird spikes in the door gaps near the top tracks.

15 – Install bird spikes in the door gaps near the top tracks.

16 – Install bird spike in the door gaps near the top tracks.

21 – Multiple exterior lights are out.

3 – Exterior light is out.

12 – Exterior light is out.

11- Bay 1, Bay 3, Bay 5– Exterior lights are out.

4C – holes in metal, door hard to open, light is not working

15-B – holes in the sheet metal need repairs.

16H – light is not working

5F – water getting under the door where new seal was installed, water getting inside new seal so when the door is opened it is leaking down in hangar

5D – light is not working